

①

Fix the left side and back plate with M5x12 self-tapping screws.

②

Fix the right side in the same way.

③

Fix the front base and back base with M6x12 screws.

④

Fix the top plate from upside.

www.hefeng-furniture.com

⑤

Install the lock rod.

⑥

Install the outer rails.

⑦

Turn the key and put the lock rod in the upper position (In Locked state), then fix the drawer. Put the blocking shaft of the lock at the top of the anti-return rail. When the drawer coming into half, turn the key and put the lock rod in the lower position (In unlocked state). Fix other drawers one by one.

⑧

Left Side: 1Pc	Right Side: 1Pc	Back Plate: 1Pc	Lock Rod: 1Pc	Top Plate: 1Pc	Front Panel: 3Pcs	Front Drawer Seal: 3Pcs	Back Drawer Seal: 3Pcs
				Front Base: 1Pc	Rail: 3Sets		M5x12 Self-tapping Screw: 6Pcs
				Back Base: 1Pc	Hanging Rod: 3Pcs	Key: 1Set	M6x12 Screw: 8Sets

①

Drawer Box: 4Pcs

②

Push the back seal to the end.

③

Install the inner rails.

④

Put the hanging rods onto the drawers.

⑤

Install the front panel.

⑥

Install the front drawer seal.

⑦